

VITRINEMEDIA

W TIMER

User Guide



VITRINEMEDIA

50 route de la Reine - 92 100 Boulogne-Billancourt - FRANCE | Tel: +33 (0)1 49 21 00 61 | sav@vitrinemia.com

1	Battery	2
2	Set up day, hour, minute, second	2
3	Set up of the calendar.....	3
3.1	Up to 20 schedules	3
3.2	15 different calendars	3
3.3	Example 1 - switch on at 7:00 am and switch off at 11:00 pm from Monday to Friday	3
3.4	Example 2 - switch on at 9:00 am and switch off at 9:00 pm every Saturday and Sunday..	4
4	Mode.....	4
5	Reset function	4
6	Time change	4

1 Battery

- VM TIMER is equipped with an internal battery enabling to keep the time and schedules for 6 months without being plugged.
- If the LCD screen is off, it means the internal battery is discharged.
- Plug in it for 10 minutes enables to charge the internal battery and then to set up the VM TIMER.

2 Set up day, hour, minute, second

Day

- While holding the **CLOCK** button, press the **WEEK** button until the desired day.
- MO: Monday / TU: Tuesday / WE: Wednesday / TH: Thursday / FR: Friday / SA: Saturday / SU: Sunday

Hour

- While holding the **CLOCK** button, press the **HOUR** button until the desired hour.

Minute

- While holding the **CLOCK** button, press the **MIN** button until the desired minute.

Second

- While holding the **CLOCK** button, press the **DEL** button until the desired second.

3 Set up of the calendar

Press the **PROG** button to display the scheduler and go through the schedules.

3.1 Up to 20 schedules

You can set up up to 20 schedules

- 1 ON: Program 1 switch-on schedule
- 1 OFF: Program 1 switch-off schedule
- 20 ON: Program 20 switch-on schedule
- 20 OFF: Program 20 switch-off schedule

3.2 15 different calendars

Each schedule can be applied on 15 different calendars:


- From 1 to 7: MO / TU / WE / TH / FR / SA / SU: Monday / ... / Sunday
- 8. MO TU WE TH FR: Monday Tuesday Wednesday Thursday Friday
- 9. SA SU: Saturday Sunday
- 10. MO TU WE TH FR SA: Monday Tuesday Wednesday Thursday Friday Saturday
- 11. MO WE FR: Monday Wednesday Friday
- 12. TU TH SA: Tuesday Thursday Saturday
- 13. MO TU WE: Monday Tuesday Wednesday
- 14. TH FR SA: Thursday Friday Saturday
- 15. MO TU WE TH FR SA SU: Monday Tuesday Wednesday Thursday Friday Saturday Sunday

3.3 Example 1 - switch on at 7:00 am and switch off at 11:00 pm from Monday to Friday

If you wish to set up your window to switch on at 7:00 am and switch off at 11:00 pm from Monday to Friday.


Press the **PROG** button to display the schedule 1 ON.

- Press successively the **WEEK** button to select the calendar MO TU WE TH FR (Monday, Tuesday, Wednesday, Thursday and Friday)
- Press 7 times on the **HOUR** button to select 7:00



Press the **PROG** button to display the schedule 1 OFF.

- Press successively the **WEEK** button to select the calendar MO TU WE TH FR (Monday, Tuesday, Wednesday, Thursday and Friday)
- Press 23 times on the **HOUR** button to select 23:00




Press the **CLOCK** button to go back to the main screen.

3.4 Example 2 - switch on at 9:00 am and switch off at 9:00 pm every Saturday and Sunday

If you wish to set up your window to switch on at 9:00 am and switch off at 09:00 pm every Saturday and Sunday.


Press the PROG button to display the schedule 2 ON.

- Press successively the **WEEK** button to select the calendar SA SU (Saturday and Sunday)
- Press 9 times on the HOUR button to select 9:00



Press the PROG button to display the schedule 2 OFF.

- Press successively the **WEEK** button to select the calendar SA SU (Saturday and Sunday)
- Press 21 times on the HOUR button to select 21:00



Press the **CLOCK** button to go back to the main screen.

4 Mode

The mode can be changed by pressing the **MODE** button.

- OFF: Window always off, timer function deactivated
- AUTO OFF: Window off during installation, timer function activated
- ON: Window always on, timer function deactivated
- ON AUTO: Window on during installation, timer function activated; this is the mode that should be used when installing the window.

5 Reset function

To reset the VM TIMER, press the **R** button for 10 seconds. You will need to use a pencil. The time and schedules will then be deleted.

6 Time change

- To switch to wintertime, while holding the **CLOCK** button, press the **HOUR** button 23 times, to remove one hour.
- To switch to summertime, while holding the **CLOCK** button, press the **HOUR** button once to add an hour.